

SMINI **Quick Start Guide**



Content

Standard



Smini

(Wind Shield included)







Quick Start Guide

**Please use the power adapter that supports 5V2A or above. While Smini is charged by battery box with batteries, please use the power adapter that supports 5V3A or QuickCharge (QC) type.

Optional

additional purchase required









Battery Box (Batteries not included)

* Please use flat top 18650 Li-ion battery.

Application Scenarios

Upright


















Power On

adapter into the power socket



Connect the cable to 5V2A(or above) Plug the power/charging cable into the Smini



Description

power button

Button/LED lights



Power on: In 'power-off' state, press the power button to turn on Smini

Power off: In 'power-on' state, press and hold the power button for 1-2 seconds and then release it to turn off

Mode switch: In 'power-on' state, press shortly the power button to switch among LOW, HIGH and TURBO modes

Power button pairing

APP pairing mode: Press and hold the power button for 5 seconds until the LED indicator flashes and hear beeper. Release the power button. The Smini is ready for APP

What it manne

	LLD	Wilatitilicalis
		Power is off
		APCO purification is working
APCO Status		APCO purification is not working
		Power is off
		LOW speed mode
		HIGH speed mode
	*	TURBO speed mode
Mode Status	or	Fan is not working
*While you activate Smini in SUVIOS APP successfully the BLUE light		

mentioned above will become GREEN •

Download SUVIOS APP

Scan the QR code on the right to download the SUVIOS APP, or go to Google Play/App Store and search for "SUVIOS"

* For the official launch time of SUVIOS APP, please contact your local distributors/dealers.



User Manual

To download the User Manual, please visit https://suvios.com/download/ or scan the QR code on the right



Customer Service

Tel: +31 (0) 15 8000 240 (NL & Europe)

Email: service@suvios.com

Warranty Card

SUVIOS Product Name: Sanitizer Model: Smini MAC Telephone Name Mobile Phone Address Warranty Purchase Date 1 year period Dealer

* Please keep the purchase receipt, in case of warranty requirements

Brise Care BV

Tel: +31 (0) 15 8000 240 Email: service@suvios.com

Address: Poortweg 4 A, 2612 PA, Delft, The Netherlands